

New Precursors for ALD of High-k Dielectrics

Roy G. Gordon, Jean-Sébastien Lehn, Yiqun Liu,
Kyoung H. Kim, Zhengwen Li and Michael Coulter
Harvard University
Cambridge, MA

Huazhi Li, Ralph Pugh and Deo Shenai
Rohm and Haas Company
North Andover, MA

Outline

ALD HfO₂ from stable Hf amidinate precursors

Stable, amorphous high-k dielectrics
=> LaLuO₃ has the best properties

Volatile Precursors for Lanthanum Oxide

ALD of La₂O₃ and LaAlO₃

Volatile Precursors for Lutetium Oxide

Why More Stable Hf and Zr Precursors?

High-k HfO₂ or ZrO₂ with very low electrical leakage needed

Carbon impurity in films increases leakage



Thermal decomposition of organic precursors adds C to films

Thermal decomposition destroys uniformity and conformality

Deposition T ~ 350 °C needed for HfAlO_x with ALD Al₂O₃

Hf alkylamide precursors decompose too quickly at 350 °C

Hafnium tetrakis(N,N'-dimethylformamidinate)




Temperature (°C)

Negligible residue after TG

=> Sufficient volatility and thermal stability for ALD

Hafnium Amidinates



R		Melting Point, °C	TG T _{1/2} °C
H	fmd	141	187
CH ₃	amd	171	221
CH ₂ CH ₃	pmd	80	251
CH ₂ CH ₂ CH ₃	bmd	<20	246

⇒ R = H is the most volatile; liquid in bubbler > 141 °C
Solid at 20 °C, soluble for use in direct liquid injection



⇒ R = CH₂CH₂CH₃ (propyl) is a liquid Hf precursor 20 °C

Thermal Stability of Hf and Zr Precursors

Precursors dissolved in mesitylene- d_12 , heated, and NMR spectra taken periodically

Hf and Zr amides completely decomposed in a few hours at 200 °C:



No decomposition of Hf or Zr amidinates during 1000 hours at 200 °C:



Thermal Stability of Hf and Zr Amidinates


No decomposition during
140 hours at 250 °C

Decomposition after
~200 hours at 280 °C



=> Hf and Zr amidinates much more stable than amides

Vaporization Rates of Hafnium Amidinates



Highest rate with Hf tetrakis(N,N'-dimethylformamidinate)

=> High evaporation rates from thermally stable liquids

ALD of HfO₂ from Amidinate Precursors

ALD Conditions

Typical bubbler temperatures 100-150 °C (mp 141 °C)

ALD with H₂O self-limiting at ~0.1 nm per cycle

ALD “window” ~150 to ~400 °C

Electrical Properties (non-optimized)

Dielectric constant >16

Breakdown field ~6 MV/cm

Stable Amorphous High-k Dielectrics


	k	Conduction band offset	Valence band offset
SiO ₂	3.9	3.5	4.4
Al ₂ O ₃	8	2.8	4.9
HfSiO ₄	12	1.5	3.4
LaAlO ₃	18	1.9	3.2
La ₂ Hf ₂ O ₇	20	2.0	2.6
GdScO ₃	22	2.0	2.5
DyScO ₃	22	2.0	2.5
LaLuO₃	32	2.1	2.1

=> LaLuO₃ has the best properties!

Advantages of LaLuO₃ as high-k dielectric

- High dielectric constant ($k \sim 32$) for amorphous phase
- Sharp interface with Si, and no low-k interlayer
- Stays amorphous and doesn't form alloys with Si or Ge after respective S/D activation anneals
- Both band offsets w.r.t Si are large (2.1 eV),
helping to achieve low leakage currents

Amidinate Precursors for Lanthanides




The R¹ and R² are alkyl groups: isopropyl, *tert*-butyl, ethyl, etc.

R³ can be an alkyl group or hydrogen


The choices of Rⁿ affect the volatility, reactivity and stability.

Thermogravimetric Analysis of Lanthanum Amidinates




=> Vaporization temperature increases with molecular mass

Vapor Pressures of Lanthanum Precursors





=> $\text{La}(\text{iPr}_2\text{-fmd})_3$ is most volatile La compound known, 60 mTorr at 100 °C



ALD of La_2O_3

Precursors:
 H_2O and

tris(N,N'-diisopropyl-
formamidinato)lanthanum
($i\text{Pr}_2\text{-fmd}$) $_3\text{La}$





=> 0.16 nm per cycle

=> negligible delay
in nucleation on SiH

Growth per La Cycle for ALD LaAlO_3

Precursors: Me_3Al , H_2O and $\text{tris}(\text{N},\text{N}'\text{-diisopropylformamidinato})\text{lanthanum} (\text{iPr}_2\text{-fmd})_3\text{La}$




Bubbler temperature 90 to 120 °C
Substrate temperature 300 °C

=> ALD saturation at
0.08 nm per La cycle

Growth even at bubbler
temperature <100 °C

Composition of ALD $\text{La}_x\text{Al}_{1-x}\text{O}_{3/2}$


Precursors: Me_3Al , H_2O and $\text{tris}(\text{N},\text{N}'\text{-diisopropylformamidinato})\text{lanthanum} (\text{iPr}_2\text{-fmd})_3\text{La}$



Growth conditions:
Bubbler temperature 120 °C
Substrate temperature 300 °C

=> Composition control
by changing ratio of
precursor doses


=> 2 x as many Al atoms
as La atoms per dose



Precursor Reactivity with SiH Surface by IR

Hf alkylamide only reacts with half of the Si-H bonds on the surface even after many cycles



La amidinate reacts with nearly all the Si-H bonds in only 3 cycles



=> **Completely uniform surface coverage by La amidinate**

Details of the infrared spectra were given in a paper this morning by J. Kwon, M. Dai, E. Langereis, Y. Chabal, K.-H. Kim and R. G. Gordon.

TEMs of ALD LaAlO_3 and GdScO_3




=> Sharp interfaces with silicon without interlayers

=> Uniform nucleation and thickness

Leakage Current through ALD La_2O_3


Vapor source: a solution of the La precursor (mp 194 °C) vaporized with an MKS MDD system



Low leakage current similar to films made from a bubbler.

=> negligible carbon contamination from solvent


Thermal Gravimetric Analysis of Lutetium tris(N,N'-diisopropylacetamidinate)



Evaporation with negligible residue

=> Sufficient volatility and thermal stability for ALD

Thermal Gravimetric Analyses of Lanthanum and Lutetium Amidinates



=> Lu amidinates are slightly more volatile than La amidinates

ALD of Lu_2O_3 and LaLuO_3

ALD experiments and film characterization are underway. . . .

Conclusions

Hf amidinates are more stable than Hf amides

Hf amidinates are suitable as ALD precursors

LaLuO₃ is a very promising high-k dielectric

La and Lu amidinates are volatile ALD precursors

Current work on ALD of LaAlO₃, Lu₂O₃ and LaLuO₃

Acknowledgements

Amidinate precursors supplied by Rohm and Haas Company

MDD liquid delivery system supplied by MKS Instruments, Inc.

Infrared data from Jinhee Kwon, Min Dai, Erik Langereis,
Leszek Wielunski and Yves J. Chabal, *Rutgers University*

Supported in part by the US National Science Foundation